

## **ACELERAIS, ACCELERATOR FOR SETTING** TIME FOR MORTAR AND CONCRETE



# Descrição

Mortar, concrete and one-layer mortar adhesive activator for curing. Suitable to get quick demoldings, with high resistances at the beginnings and at the ends, also against freeze and under water. It is used with dose from 0,125 to 0,5000 litres by cement sack.

# **Aplication**

ACELERAIS is used to obtain quick turnovers, concrete characterised by high initial and final resistances, concrete structures that require the quick formation of passable decks, concrete at low temperatures, with water contact and even when completely immersed in water, etc. It accelerates the setting time of one coat mortars.

### **Surface preparation**

It is recommended not to use aggregates or water after being exposed to frost, under temperatures below freezing point(if necessary, heat the water and aggregates at the moment to be used).

### **Modes of application**

ACELERAIS is diluted in the mixing water in a ratio proportional to the setting speed. (It is recommended to undergo prior testing so as to determine the





required dosage according to temperature, quantity and type of cement used).

- The required dose is 0.5 to 2% in accordance to cement weight
- ACELERAIS is added to the mixing water in the recommended proportion in the cement mixer.
- It is advisable to use concrete and mortars rich in cement and to apply them once they are readily mixed.
- Do not use water having frost on the surface.

### Clean up

Clean using large amounts of water.

## **Data sheet**

Density1,2 Kg./Lt. +- 0,05.

Colour/sTransparent

#### **Performance**

0,125 to 0,500 l per bag of cement.

#### **Storage**

It is recommended to store this product for 3 years in tightly closed original closed packages in a cool dry place and under mild temperatures.

# Security



## **Indications of danger:**

H319: H319: Causes serious eye irritation.





### **Prudence advice:**

P264: P264: Wash thoroughly after handling.

P280: P280:Wear protective gloves/protective clothing/eye protection/face protection.

P305+P351+P338: P305+P351+P338:IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P337+P313: P337+P313:If eye irritation persists: Get medical advice/attention.



