

# DEAIS LAVA, RETARDER RELEASING-AGENT OF SURFACE SETTING FOR FACING AGGREGATE.



# Descrição

Gelatinous release agent in liquid shape, soluble in water, made of to delay the setting-time in surface layers of mortars or concrete, allowing an easy releasing and subsequent concrete cleaning leaving the aggregates exposed. It is applied without dilute or slightly diluted. It is soluble in water, anticorrosive, is free of chloride and is no toxic by inhalation.

# **Aplication**

To obtain a finish in the face side on aggregates, pavements, concrete prefabs, faced concrete, concretes in general where is required to obtain an effective support for further renders.

## **Surface preparation**

The surface must be clean and free of loose particles and suitabily waterproofing before application of DEAIS LAVA.

#### **Modes of application**

Shake well the content of the package before applying the product.

- -Apply without dilute or slightly diluted by brush.
- -DEAIS LAVA does not require that the product is dry for the placing of concrete into the moulds but it is only





Email.: desarrollo@teais.es

properly to the moulds with a few depth in which a treatment by one of the sides is required and not in the sides beside the mould.

Waterproof properly the casings, protect them from the rain(avoid the draggin) before applying DEAIS LAVA. Remove forms after 2 - 3 days when the mortar or concrete achieves enough resistance.

Just after the forms are removed the concrete surface must be cleaned with a strong jet (before 2 hours), cleaning carefully with a brush to may possible that the aggregate can be seen.

#### Clean up

With plenty of water.

# Data sheet

Density1,06 Kg./Lt. ± 0,05 kg/Lt

SolubilitySoluble in water.

AspectViscous liquid.

#### **Performance**

3,5-5,5 sqm per L

### **Storage**

1 year in their original packages and tightly closed, protected from the weather and in dry and open-air places.

# Security



## **Indications of danger:**

H319: Causes serious eye irritation.





#### **Prudence advice:**

P264: Wash? thoroughly after handling.

P280: Wear protective gloves/protective clothing/eye protection/face protection.

P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P337+P313: If eye irritation persists: Get medical advice/attention.

## **Supplementary information:**

EUH208: EUH208: Contains . May produce an allergic reaction.





Email.: desarrollo@teais.es