

## EMPLAIS RENOVACIÃ"N, POWDER PLASTER FOR INTERIOR SUPPORTS.



# Descripción

White powder product that mixed with water becomes in a plastic blend suitable for plasting cracks and scalings in walls and floors.

# **Aplication**

To eliminate unevenness in the surfaces to paint on. Only for interiors. For levelling in renders. In the elimination of cracks. In all works that requires a fast finish.

### **Surface preparation**

The surface must be clean and perfectly dry, free of greases, salt and dust, compact and without loose parts.

### Modes of application

It must be blended with water until obtaining the necessary plastic dough in order to can be applied easily. Applying by a no tootled trowel or spatula.

Seal it once it is dried with TEAIS paints which are the only compatible with it.

For painting on the plaster 15 minutes have to be spent since the last application.





Email.: desarrollo@teais.es

#### Clean up

With plenty of clean water.

## Data sheet

Water absorption 50 ± 5%

Powder density $0,600 \pm 0,05$  g/cc.

Mass of density  $1,650 \pm 0,05$  g/cc.

Water retention> 97%

Capillarity< 1,5 % 60 minutes

Colour/sWhite

Curing density  $1,550 \pm 0,05$  g/cc.

Open time 20 miunutes approximately

#### **Performance**

1 sqm per kg in layer of 1 mm.

### **Storage**

2 years in their original sacks, tightly closed and keeping from the wether.

# **Security**





## **Indications of danger:**

H315: H315: Causes skin irritation.





Email.: desarrollo@teais.es

H317: H317: May cause an allergic skin reaction.

H318: H318: Causes serious eye damage.

H335: H335:May cause respiratory irritation.

#### **Prudence advice:**

P271: P271:Use only outdoors or in a well-ventilated area.

P280: P280:Wear protective gloves/protective clothing/eye protection/face protection.

P302+P352: P302+P352:EIF ON SKIN: Wash with plenty of soap and water.

P304+P340: P304+P340:IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing.

P305+P351+P338: P305+P351+P338:IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P310: P310:Immediately call a POISON CENTER or doctor/physician.

P403+P233: P403+P233: Store in a well-ventilated place. Keep container tightly closed.

P501: P501:Dispose of contents/container in accordance with local/regional/national/international regulation





Email.: desarrollo@teais.es