

PANIS GRUESO, Self-leveling mortar of gross thickness for interior and outside floors.



Description

Mortar for the regularization of pavements, it is a powder product and blended with water (2.5 l for Panis 10kg), it forms a self-leveling mortar, suitable to regulate floor surfaces, gray cement colur. It has a high compressive strength. The price depends on the quantity of the order. Factory price

Aplication

Levelling of pavement, in fine and medium coat, on support of open pore like mortar and concrete no polished. Training support plane for the placement of floor coverings such as ceramic tiles, porcelain, marble, natural stones, carpets, parquet, synthetic, etc..

Surface preparation

Must be clean, firm, possess good porosity and lacking damp. Cementitious support must be at least a month. They previously repaired cracks and fissures.

Modes of application

Clean up





With clean water while the product is fresh, once hardened can only be removed by mechanical means.

Data sheet

Water absorption

Adherence

Capillarity

Colour/s

Curing density

Mass of density

Compressive resistance

Flexural strength resistance

Temperature of work

Open time

Type

Thickness

Performance

1,5 kg per sqm with 1 mm layer

Storage

Two years, in their original bags, tightly closed, without exposing to extreme temperatures, protected from the weather and in dry and ventilated.

Security









Indications of danger:

H315: H315: Causes skin irritation.

H317: H317: May cause an allergic skin reaction.

H318: H318: Causes serious eye damage.

H335: H335:May cause respiratory irritation.

Prudence advice:

P271: P271:Use only outdoors or in a well-ventilated area.

P280: P280:Wear protective gloves/protective clothing/eye protection/face protection.

P302+P352: P302+P352:IF ON SKIN: Wash with plenty of soap and water.

P304+P340: P304+P340:IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing.

P305+P351+P338: P305+P351+P338:IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P310: P310:Immediately call a POISON CENTER or doctor/physician.

P403+P233: P403+P233: Store in a well-ventilated place. Keep container tightly closed.

P501: P501:Dispose of contents/container in accordance with local/regional/national/international regulation





Email.: desarrollo@teais.es