

# PROTEN, PROTECTOR AGENT FOR MARBLE, GRANITE AND SLATE SURFACING.



# Descripción

PROTEN is protector liquid for countertops made of marble and granite. The application of PROTEN form a protective film that repels greases and oils both cold and hot avoiding stains on the protected surface.

# **Aplication**

The application of one coat of PROTEN protects marble and granite surface from stains of greases, oils and other agressive substances. PROTEN is suitable for the protection of countertops in bathrooms and kitchens penetrating into the substrate and without leaving a visible coat removing greases and oils both cold and hot, avoiding stains on the protected surface.

#### **Surface preparation**

The surface where PROTEN is applied on must be clean and dry.

## **Modes of application**

Shake the product before applying.

- Apply on the support by brush or short nap roller.





- According with the support and its absoption one or several coats can be applied.
- Before applying the next coat the first one must be dried.
- Don't apply on wet surfaces or RH over 85%.

#### Clean up

Tool must be cleaned with DISOLUAIS.

## Data sheet

Density0,8 kg/lt Dry upon touching 30 minutes AspectTraslucent liquid

#### **Performance**

From 4 to 6 sqm

### Storage

3 years in their original packages, protected from the weather and stored in cool and dry place.

# Security





## **Indications of danger:**

H225: Highly flammable liquid and vapour.

H319: Causes serious eye irritation.

H336: May cause drowsiness or dizziness.





#### **Prudence advice:**

P210: Keep away from heat/sparks/open flames/hot surfaces. ? No smoking.

P280: Wear protective gloves/protective clothing/eye protection/face protection.

P303+P361+P353: IF ON SKIN (or hair): Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower.

P304+P340: IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing.

P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P370+P378: In case of fire: Use? for extinction.

P403+P233: Store in a well-ventilated place. Keep container tightly closed.

P501: Dispose of contents/container in accordance with local/regional/national/international regulation

## **Supplementary information:**

EUH208: EUH208: Contains . May produce an allergic reaction.



