

TEAIS CLEANER, CONCENTRATED NEUTRAL DETERGENT.



Descripción

TEAIS CLEANER cleans carefully all types of pavements and coverings, suitable for delicate surfaces and for the final cleaning natural stone in works with polished pavements. It cleans without damage on materials. Is a very concentrated product which can be used in several dilutions depending on the required cleaning. Suitable for the maintenance on waxed surfaces.

Aplication

Suitable for cleaning pavements and coverings. Suitable for cleaning pavements made of natural stone with a polished finish. Porcelain stoneware, ceramic and glazzed stoneware, extruded stoneware, cement, wood, plastic sheets, linoleum, rubber and PVC, etc. TEAIS CLEANER is a cleaner suitable for maintenance.

Surface preparation

It is no necessary.

Modes of application

The product can be diluted on water in proportion 1:30 to 1:200.

- For the final cleaning on delicate surfaces the proportion must be 1:30.
- Spreed it on the pavement by mop or rotative machine with soft disc. Pick up the waste and rinse with water.
- For using with clean and dry machines in high dilutions.





- For the usual maintenance in all types of surfaces, TEAIS CLEANER must be diluted in warm water in proportion of 1:200 and wash normally. For a deeper cleaning must be used higher dilutions.

Clean up

The tools must be cleaned with plenty of water.

Data sheet

Colour/slemony yellowish

Density1,0 kg/lt

PH7,5

Odourlemon

Performance

From 50 to 1500 sqm according dilution.

Storage

3 years in their original packages, protected from the weather and stored in a cool and dry place.

Security



Indications of danger:

H315: H315: Causes skin irritation.

H319: H319: Causes serious eye irritation.





Prudence advice:

P264: P264: Wash thoroughly after handling.

P280: P280:Wear protective gloves/protective clothing/eye protection/face protection.

P302+P352: P302+P352:IF ON SKIN: Wash with plenty of soap and water.

P305+P351+P338: P305+P351+P338:IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P332+P313: P332+P313:If skin irritation occurs: Get medical advice/attention.

P337+P313: P337+P313:If eye irritation persists: Get medical advice/attention.

Supplementary information:

EUH208: EUH208: Contains mixture of: 5-chloro-2-methyl-4-isothiazolin-3-one [EC no. 247-500-7] and 2-methyl-2H -isothiazol-3-one [EC no. 220-239-6] (3:1). May produce an allergic reaction.



