



Descripción

Bonding agent to apply on supports with low adherence. Its application allows the application on ceramic surfaces both walls and floors for the subsequent application of screeds, levelling pastes, cement-base adhesives, etc.. Very suitable as bonding agent on floors because it doesn't have tacking.

Aplication

Adirres is applied on ceramic supports, wood, and once dry allows the application of levelling pastes and cement-base adhesives for the application of claddings, application of screed layers. Etc

Surface preparation

The surface must be clean, dry, dust-free and loose particles, firm and resistant.

Modes of application

The content of container must be homogenized.

- Apply by brush or roller on the clean and dry support.
- First, apply one coat and let it dry. The applied coat on the product can not be thick in order to preserve its micro-rough texture.
- Drying time for mortar or cement-base adhesive application should be 12 hours at list at 20°C and 65%

HR(relative humidity).

-Once dry, proceed to the levelling pastes or mortars application for floors and cement-base adhesive or thixotropic mortars in case of walls.

-Water should not added to the product.

Clean up

Tools must be cleaned with plenty of water while the material is wet.

Data sheet

Colour/sLight yellow.

Density0,93 Kg/Lt

AspectViscous liquid.

Drying time12 hours for mortar or glue cement application

Temperature of work20°C and 65 Relative Humidity.

Performance

4 sqm/Lt

Storage

Two years in their original packages protected from the weather and stored in a dry and fresh place.

Security

Supplementary information:

EUH208: Contains . May produce an allergic reaction.



📍 Avda. da Enerxía, nº 153, Pol. Ind. de Sabón
15143 Arteixo, A Coruña
☎ Telf.: 981 602 111
📠 Fax.: 981 601 508
✉ Email: desarrollo@teais.es

síguenos en:



EUH210: Safety data sheet available on request.



📍 Avda. da Enerxía, nº 153, Pol. Ind. de Sabón
15143 Arteixo, A Coruña
☎ Telf.: 981 602 111
📠 Fax.: 981 601 508
✉ Email: desarrollo@teais.es

síguenos en:

