



MORPI BASE CAL, MORTAR USED FOR LAYING AND GROUTING PURPOSES



Descripción

Mortar made with greasy lime, without retraction, waterproofing, suitable for placing and grouting of masonry, ashlar and face side brick. Is is mixtured with water until obtain the properly thickness. Colour according color chart.

Aplication

It is used in masonry made of concrete blocks and brick slips. Also for waterproofing walls made of brick slips. It is used for joints in walls and facades made of stone

Surface preparation

The background of application must be clean, free of dust, loose particles, grease, oil, by being slightly damp.

Modes of application

Use a clean container to mix MORPI with water in a proportion of $18 \pm 2\%$ until reaching the desired consistency.

- Apply with a trowel in the same manner as a traditional mortar. The difference is that MORPI allows for a second layer, with a waterproofing and decorating effect at the same time.



Clean up

Clean using large amounts of water.

Data sheet

Water absorption $25 \pm 2\%$

Powder density $1,400 \pm 0,05$ g/cc.

Mass of density $1,800 \pm 0,05$ g/cc.

Curing density $1,700 \pm 0,05$ g/cc

Capillarity $< 0,5\%$ a 60 minutes

Water retention $> 97\%$

Adherence > 3 kg/cm²

Compressive resistance > 20 kg/cm²

Resistance to longitudinal tear > 12 kg/cm²

Colour/sgrey, ocre, black, and other by order

Temperature of work 5 to 30°C

Composition

Performance

10 to 15 kg per sqm of wall

Storage

It is recommended to store this product for 2 years in its tightly closed original packages in a cool dry place protected against bleakness.

Security



Avda. da Enerxía, nº 153, Pol. Ind. de Sabón

15143 Arteixo, A Coruña

Tel.: 981 602 111

Fax.: 981 601 508

Email: desarrollo@teais.es

síguenos en:



Indications of danger:

H315: Causes skin irritation.

H317: May cause an allergic skin reaction.

H318: Causes serious eye damage.

Prudence advice:

P261: Avoid breathing dust/fume/gas/mist/vapours/spray.

P264: Wash ? thoroughly after handling.

P280: Wear protective gloves/protective clothing/eye protection/face protection.

P302+P352: IF ON SKIN: Wash with plenty of soap and water.

P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P310: Immediately call a POISON CENTER or doctor/physician.

P333+P313: If skin irritation or rash occurs: Get medical advice/attention.

P501: Dispose of contents/container in accordance with local/regional/national/international regulation

