



RAIS FN-PLUG, ULTRA FAST CEMENT FOR WATER LEAKS SEALING



Description

Cement ultra fast to seal water leaks immediately. For retaining walls, basements, lift pits, etc..

Application

Rais is used to seal water leaks in basements concrete walls , elevator pits, masonry, rocks, etc, as a previous treatment to waterproofing, allowing to the entry of water and making the subsequent waterproofing works with suitable products as Cepis or Cepis Super.

Surface preparation

Clean the watertight area removing loose or poorly adhered parts, it's suitable that the material could be hosted in any cavity which facilitates the blocking work.

Modes of application

Apply RAIS PLUG by spreading the powder over the leaking area



until it starts drying and finally hardens on the support.

- It can be mixed with water in small quantities by using rubber gloves as hand protection and blocking the leaking areas, by pressing down with the hands whilst the product hardens (from 2 to 5 minutes according to temperature).
- When handling this product, it is necessary to wear gloves for hand protection.

Clean up

Tools must be cleaned with plenty of water while the material is wet, once hardened can only be removed by mechanical means.

Data sheet

Colour/s grey/beige

PH From 11.0 to 13.5 in saturated solution

End of setting time 1,5 minutes at 20°C

End of setting time 2 minutes at 20°C

Compressive resistance > 60 kg/cm² at 1 hour

Compressive resistance > 150 kg/cm² at 3 hours

Compressive resistance > 250 kg/cm² at 7 days

Compressive resistance > 400 kg/cm² at 28 days

Performance

According to use

Storage

One year in their original packages, protected from the weather and temperature changes.

Security



📍 Avda. da Enerxía, nº 153, Pol. Ind. de Sabón

15143 Arteixo, A Coruña

☎ Telf.: 981 602 111

📠 Fax.: 981 601 508

✉ Email: desarrollo@teais.es

síguenos en:



Indications of danger:

H315: H315:Causes skin irritation.

H317: H317:May cause an allergic skin reaction.

H335: H335:May cause respiratory irritation.

Prudence advice:

P101: P101:If medical advice is needed, have product container or label at hand.

P102: P102:Keep out of reach of children.

P264: P264:Wash thoroughly after handling.

P280: P280:Wear protective gloves/protective clothing/eye protection/face protection.

P302+P352: P302+P352:IF ON SKIN: Wash with plenty of soap and water.

P304+P340: P304+P340:IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing.

P403+P233: P403+P233:Store in a well-ventilated place. Keep container tightly closed.

P501: P501:Dispose of contents/container in accordance with local/regional/national/international regulation

