



INTEGRADOR REPAIS, REPAIS EFFECT REDUCING LIQUID.



Descripción

Liquid product used when there is a over application of REPAIS. The product contributes to reduce the layer and decreases stains from application.

Aplication

It is applied when there is an excess of application of REPAIS, reducing the layer and the effects of stains produced by water-repellent application.

Surface preparation

No necessary.

Modes of application

Homogenize well the product before applying.

- Apply on the support by brush to achieve the required integrating effect.
- Can be done in more than one application.

Clean up



Avda. da Enerxía, nº 153, Pol. Ind. de Sabón
15143 Arteixo, A Coruña
Telf.: 981 602 111
Fax.: 981 601 508
Email: desarrollo@teais.es

síguenos en:



Tools must be cleaned with DISOLUAIS N.

Data sheet

Density 0,85 kg/Lt +/- 0,05 kg/Lt

Aspect colourless

Odour characteristic

Performance

1 to 2 sqm/Lt according required cleaning.

Storage

3 years in their original packages tightly closed and stored in cool and dry places.

Security



Indications of danger:

H225: Highly flammable liquid and vapour.

H302: Harmful if swallowed.

H304: May be fatal if swallowed and enters airways.

H315: Causes skin irritation.

H319: Causes serious eye irritation.

H361: Suspected of damaging fertility or the unborn child .

H371: May cause damage to organs .

H373: May cause damage to organs through prolonged or repeated exposure .



📍 Avda. da Enerxía, nº 153, Pol. Ind. de Sabón
15143 Arteixo, A Coruña
☎ Telf.: 981 602 111
📠 Fax.: 981 601 508
✉ Email: desarrollo@teis.es

síguenos en:



Prudence advice:

P210: Keep away from heat/sparks/open flames/hot surfaces. ? No smoking.

P280: Wear protective gloves/protective clothing/eye protection/face protection.

P302+P352: IF ON SKIN: Wash with plenty of soap and water.

P303+P361+P353: IF ON SKIN (or hair): Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower.

P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P308+P313: IF exposed or concerned: Get medical advice/attention.

P370+P378: In case of fire: Use ? for extinction.

P501: Dispose of contents/container in accordance with local/regional/national/international regulation

Supplementary information:

EUH066: Repeated exposure may cause skin dryness or cracking.